

The DENSO logo is located in the top left corner. It consists of a black rectangular background with a white curved shape on the left side, resembling a stylized 'D' or a lens. The word "DENSO" is written in white, italicized, sans-serif capital letters to the right of this shape.

Diesel Injection Pump

SERVICE MANUAL

**Common Rail System for
The MITSUBISHI FUSO FIGHTER 6M60 Engine
OPERATION**

April, 2004

DENSO CORPORATION

00400071E

© 2004 DENSO CORPORATION

All Rights Reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of the publisher.

TABLE OF CONTENTS

1. GENERAL DESCRIPTION	1
1-1. Outline	1
2. PRODUCT APPLICATION LIST	2
2-1. Vehicle Specifications	2
2-2. Component Part Numbers	2
3. GENERAL DESCRIPTION OF MAIN NEW FEATURES	3
3-1. Common Rail Specifications and Engine Elements	3
3-2. System Configuration	3
4. MAIN FUNCTIONAL PARTS	4
4-1. Changes to the Main Functional Parts	4
4-2. Supply Pump	4
4-3. Rail	5
4-4. Injector	7
4-5. Sensor Additions and Changes	9
5. CONTROL OPERATION CHANGES	11
5-1. Idle-Up	11
6. ECU RELATED	12
6-1. External Wiring Diagram	12
6-2. Terminal Layout	13
6-3. Terminal Symbol Explanation	13
7. DIAGNOSTIC TROUBLE CODES (DTC)	16
7-1. DIAGNOSTIC TROUBLE CODES LIST	16

1. GENERAL DESCRIPTION

1-1. Outline

- This manual describes the common rail system installed in the 6M60 engine of the Mitsubishi Fuso Fighter. The most significant difference to the conventional common rail system is that this system employs a compact and lightweight HP4 supply pump, and a G2 injector with better response. For more details on the common rail system, refer to service manual No. 00400041 "Common Rail System for HINO J05D/J08E Type Engine", issued in October 2003.

2. PRODUCT APPLICATION LIST

2-1. Vehicle Specifications

Vehicle Name	Engine Model	Engine Displacement	Remarks
Mitsubishi Fuso Fighter	6M60	7,545 cc	

2-2. Component Part Numbers

Part Name	DENSO P/N	Mitsubishi P/N	Remarks
Injector	095000-5450	ME302143	
Rail	095440-0570	ME302292	
Flow Damper		ME743861	Rail Component Parts
Pressure Limiter		ME743862	
Pc sensor		ME743864	
Supply Pump	294050-0050	ME302145	12V Specification
ECU	275800-3401	ME302751	6M60T1
	275800-3411	ME302752	6M60T2
	275800-3451	ME302986	6M60T1 (Allison AT)
Boost Pressure Sensor	079800-5580	MK369080	
TDC (MRE) Sensor	949979-1420	ME301026	
NE (MPU) Sensor	029600-0570	MC885578	
Intake Air Temperature Sensor	071500-2571	ME352426	
Fuel Temperature Sensor	179730-0030	MC885579	
Accelerator Position Sensor	198300-7030	ME162376	


3. GENERAL DESCRIPTION OF MAIN NEW FEATURES

3-1. Common Rail Specifications and Engine Elements

		FK6
Common Rail Specifications	Main Elements	HP-4 + G2
	Pressure Used	170MPa
Engine Elements	Model	L6, TI, 4 valves.
	Engine Displacement	7.5L
	Output	199kW/2700rpm
	Torque	785N•m/1400rpm

3-2. System Configuration

A. Overall System



4. MAIN FUNCTIONAL PARTS

4-1. Changes to the Main Functional Parts

- This section describes only the functional parts that have changed significantly.


4-2. Supply Pump

A. Changes

Significant changes are listed below.


Model			HP-4
Rotation Ratio Np : Ne			1 : 1
Maximum Speed			4000rpm
Direction of Rotation			Counter clockwise (viewed from actuating side).
Component Parts	Feed Pump		Trochoid Type
	SCV	Rated Voltage	12V
		Type	Normally Open
	Plunger	Diameter × No.	φ8.5 × 3
		Lift Amount	8.8mm
	Fuel Temperature Sensor		2.45 ± 0.24kΩ (20°C)

B. External View




C. Construction and Operation

- The ring cam is press fitted into an eccentric position relative to the cam shaft. The ring cam is a triple-lobed cam.




- As the camshaft makes one rotation, the positional relationship between the ring cam and the plunger remains unchanged. Each plunger makes a single reciprocal movement to pump the fuel. Fuel is drawn in by the feed pump, and the suction quantity is adjusted by the SCV (Suction Control Valve).




4-3. Rail

A. External View




B. Rail Pressure Sensor

The basic principles and construction are the same as for the conventional model. The pressure detection range has been changed to accommodate the increase in pumping pressure from the supply pump.




C. Flow Limiter

A flow limiter is employed instead of a flow damper. As with the flow damper, the flow limiter closes the fuel passage to prevent further flow of fuel in the event of an excessive fuel flow. If an abnormal flow occurs, the high pressure forces the piston up. This closes the fuel passage leading to the seat.



D. Pressure Limiter

The construction and operating principles are the same as for the conventional model. The operating pressure has changed.




4-4. Injector

A. Outline

A compact, energy-saving solenoid-control type TWV (Two-Way Valve) injector has been adopted.

B. Construction



C. Operation

The TWV (Two-Way Valve) solenoid valve opens and closes the outlet orifice passage to control both the pressure in the control chamber, and the start and end of injection.

a. Non-Injection


When no current is supplied to the solenoid, the TWV (solenoid valve) is pushed downward by the spring, closing the outlet orifice. This equalizes the control chamber pressure forcing the command piston down and the pressure forcing the nozzle needle up. A state of non-injection results because the nozzle needle closes due to the nozzle spring force and the difference in areas to which pressure is being applied.

b. Injection

When current is initially applied to the solenoid, the attraction of the solenoid pulls the TWV (solenoid valve) up, opening the outlet orifice and allowing fuel to flow out of the control chamber. After the fuel flows out, pressure in the control chamber decreases, pulling the command piston up. This causes the nozzle needle to rise and injection to start.


c. End of Injection

When current continues to be applied to the solenoid, the nozzle reaches its maximum lift, where the injection rate is also at the maximum level. When current to the solenoid is turned OFF, the TWV (solenoid valve) falls and closes the orifice. Fuel then flows into the control chamber via the inlet orifice, increasing pressure and causing the nozzle needle to close immediately and injection to stop.




C. Intake Air Temperature Sensor

This sensor is used to detect the intake air temperature in order to correct the injection quantity, injection timing and injection pressure. Similar to the other temperature sensors, it uses a thermistor. The temperature versus resistance characteristics are shown in the diagram below.



D. Intake Air Pressure Sensor (PIM)


This is a type of semi-conductor pressure sensor. It utilizes the characteristic whereby electrical resistance changes when pressure is applied to silicon crystal. The intake air pressure sensor is used to correct the full load injection quantity data programmed in the engine ECU. The relationship between pressure and output voltage is shown in the diagram below.



5. CONTROL OPERATION CHANGES

5-1. Idle-Up


- If the conditions shown in the diagram on the right overlap, the idling speed is set to a fixed value.



6. ECU RELATED


6-1. External Wiring Diagram

*1: For the 6M60T1 engine.



Q000681E

6-2. Terminal Layout



6-3. Terminal Symbol Explanation

A. Terminals No. 1 to 34

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
1	-	-	18	CASEGND	Case ground
2	-	-	19	KWP2000	MUT-3
3	-	-	20	-	-
4	-	-	21	AD1	Accelerator position sensor 1
5	+B	+VB	22	AD2	Accelerator position sensor 2
6	+B	+VB	23	-	-
7	+B	+VB	24	-	-
8	TAC1	Tachometer signal	25	AD19	Temperature sensor 4 for after-treatment (following EGR merging).
9	TAC2	NE OUT	26	AD20	N correction resistor
10	POUT1	Development output (Q-OUT)	27	VS1	Vehicle speed sensor
11	POUT2	PWMACC	28	-	-
12	-	-	29	-	-
13	-	-	30	AD14	IMC volume
14	-	-	31	AD15	PTO accelerator position sensor
15	-	-	32	-	-
16	-	-	33	-	-
17	-	-	34	-	-

B. Terminals No. 35 to 69

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
35	+BF	SURGE OUT 1	53	SW7	Air conditioning switch
36	-	-	54	A-GND4	Sensor GND4
37	-	-	55	A-GND5	Sensor GND5
38	-	-	56	SW1	Key switch
39	NE-SLD	NE-SLD	57	A-VCC4	Sensor power supply 4
40	NE+	Engine speed sensor +	58	SW8	Neutral switch
41	NE-	Engine speed sensor -	59	SW10	Warm-up switch
42	-	-	60	-	-
43	OUT2	Relay to prevent continuous starter energization.	61	SW17	Accelerator switch

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
44	-	-	62	AD21	Quantity correction resistor
45	-	-	63	-	-
46	SW1	Key switch	64	-	-
47	-	-	65	-	-
48	SW2	Starter switch	66	SW9	PTO switch
49	SW3	Exhaust brake switch	67	SW11	AT recognition switch
50	-	-	68	SW16	Diagnosis switch
51	SW5	Idle-up cancel switch	69	-	-
52	SW6	Clutch switch 1			

C. Terminals No. 70 to 101

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
70	OUT19	Glow relay actuation relay	86	-	-
71	-	-	87	-	-
72	GND	ECU analog GND	88	-	-
73	GND	ECU analog GND	89	-	-
74	OUT17	ECU main relay	90	-	-
75	OUT18	ECU main relay	91	-	-
76	+BF	SURGE OUT 2	92	-	-
77	SW27	Diagnosis memory clear switch	93	-	-
78	-	-	94	-	-
79	-	-	95	-	-
80	SW15	Exhaust brake cut switch	96	-	-
81	-	-	97	-	-
82	S-OUT1	Diagnosis light 1 (red)	98	-	-
83	S-OUT2	Diagnosis light 2 (orange)	99	-	-
84	S-OUT3	Glow light	100	-	-
85	S-OUT4	Exhaust brake light	101	-	-

D. Terminals No. 102 to 136

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
102	P-GND	POWER GND	120	G	G sensor +
103	TWV1	Injector drive signal 1	121	AD4	Rail pressure sensor 1
104	TWV3	Injector drive signal 3	122	-	-
105	TWV5	Injector drive signal 5	123	A-VCC3	Sensor power supply 3
106	COMMON1	Injector drive power supply 1-1	124	-	-
107	COMMON1	Injector drive power supply 1-2	125	A-VCC2	Sensor power supply 2
108	-	-	126	A-VCC1	Sensor power supply 1
109	-	-	127	-	-

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
110	-	-	128	AD3	Boost sensor
111	OUT12	Exhaust brake MV1	129	-	-
112	-	-	130	-	-
113	-	-	131	G-GND	G sensor
114	-	-	132	AD5	Rail pressure sensor 2
115	-	-	133	G-VCC	CAM ANGLE VCC (5V)
116	-	-	134	A-GND1	Sensor GND1
117	-	-	135	A-GND2	Sensor GND2
118	-	-	136	A-GND3	Sensor GND3
119	-	-			

E. Terminals No. 137 to 167

No.	Terminal Name	Signal Name	No.	Terminal Name	Signal Name
137	TWV2	Injector drive signal 2	153	-	-
138	TWV4	Injector drive signal 4	154	AD6	Intake air temperature sensor (before
139	TWV6	Injector drive signal 6	155	AD7	Coolant temperature sensor
140	P-GND	POWER GND	156	-	-
141	P-GND	POWER GND	157	CAN1H	CAN1 HIGH
142	COMMON2	Injector drive power supply 2-1	158	CAN1L	CAN1 LOW
143	COMMON2	Injector drive power supply 2-2	159	-	-
144	SCVLO	HP3 and HP4 suction control valve drive signal 1	160	-	-
145	SCVLO	HP3 and HP4 suction control valve drive signal 2	161	-	-
146	SCVHI	HP3 and HP4 suction control valve power supply 1	162	AD8	Fuel temperature sensor 1 (leak side)
147	SCVHI	HP3 and HP4 suction control valve power supply 2	163	AD9	Fuel temperature sensor 2
148	-	-	164	-	-
149	-	-	165	-	-
150	-	-	166	-	-
151	-	-	167	-	-
152	-	-			

7. DIAGNOSTIC TROUBLE CODES (DTC)

7-1. DIAGNOSTIC TROUBLE CODES LIST

DG Code	Source	Malfunction Outline
P0107	Atmospheric pressure sensor	Output from the atmospheric pressure sensor is too low.
P0108	Atmospheric pressure sensor	Output from the atmospheric pressure sensor is too high.
P0112	Intake air temperature sensor	Output from the intake air temperature sensor is too low.
P0113	Intake air temperature sensor	Output from the intake air temperature sensor is too high.
P0117	Coolant temperature sensor	Output from the coolant temperature sensor is too low.
P0118	Coolant temperature sensor	Output from the coolant temperature sensor is too high.
P0121	Accelerator position sensor	Output from accelerator position sensors No. 1 and No. 2 is inconsistent.
P0122	Accelerator position sensor No. 1	Output from the accelerator position sensor is too low.
P0123	Accelerator position sensor No. 1	Output from the accelerator position sensor is too high.
P0187	Fuel temperature sensor	Output from the fuel temperature sensor is too low.
P0188	Fuel temperature sensor	Output from the fuel temperature sensor is too high.
P0191	Rail pressure sensor	Output from the rail pressure sensor is fixed at a middle value.
P0192	Rail pressure sensor	Output from the rail pressure sensor is too low.
P0193	Rail pressure sensor	Output from the rail pressure sensor is too high.
P0200	Injector COM1	COM1 is open or short circuited; or TWV1, TMV3 or TWV5 is open or short circuited.
P0201	Injector TWV	Open circuit in the TWV1 wiring or injector coil.
P0202	Injector TWV	Open circuit in the TWV5 wiring or injector coil.
P0203	Injector TWV	Open circuit in the TWV3 wiring or injector coil.
P0204	Injector TWV	Open circuit in the TWV6 wiring or injector coil.
P0205	Injector TWV	Open circuit in the TWV2 wiring or injector coil.
P0206	Injector TWV	Open circuit in the TWV4 wiring or injector coil.
P0219	Overrun	Engine is overrunning.
P0222	Accelerator position sensor No. 2	Output from the accelerator position sensor is too low.
P0223	Accelerator position sensor No. 2	Output from the accelerator position sensor is too high.
P0227	PTO accelerator position sensor	Output from the PTO accelerator position sensor is too low.
P0228	PTO accelerator position sensor	Output from the PTO accelerator position sensor is too high.
P0234	Abnormally boost pressure	Boost pressure is excessive or insufficient.
P0237	Intake air pressure sensor	Output from the intake air pressure sensor is too low.
P0238	Intake air pressure sensor	Output from the intake air pressure sensor is too high.
P0251	Fuel leak	Fuel leak in the injection system or fuel system.
P0252	Pressure limiter	Pressure limiter is operating.
P0253	Abnormally high pressure 2	Output from the rail pressure sensor is over the higher upper limit.
P0254	Abnormally high pressure 1	Output from the rail pressure sensor is over the lower upper limit.
P0255	Supply pump	Rail pressure exceeds the specified duration or is over the specified value. (Specified speed range.)
P0256	Supply pump	Rail pressure exceeds the specified duration or is over the specified value (lower pressure and longer duration than PO255). (Medium to high speed range.)

DG Code	Source	Malfunction Outline
P0257	Supply pump	Poor pumping in the supply pump No. 1 cylinder.
P0335	Engine speed sensor	No signal output from the engine speed sensor.
P0340	TDC sensor	No signal output from the TDC sensor.
P0380	Glow relay	BATT short in the output to the glow relay. Open or GND short in the glow relay output.
P0500	Vehicle speed sensor	Open or short circuit in the vehicle speed sensor; frequency is too high; no output.
P0506	IMC volume	IMC volume signal is too low.
P0507	IMC volume	IMC volume signal is too high.
P0510	IDLE switch	IDLE switch is seized closed.
P0600	SLD system	Communication error between the vehicle speed control ECU and engine ECU or vehicle speed sensor.
P0605	CPU (in the engine ECU)	Main CPU malfunction or watchdog malfunction.
P0616	Starter prohibition relay	BATT short in the output to the starter prohibition relay.
P0617	Starter prohibition relay	Open circuit (external) or GND short in the output to the starter prohibition relay.
P1121	Intake throttle valve	Open circuit, GND short or BATT short in the output to valve MV1.
P1171	Injection correction resistance value	Injection correction resistance value is too low.
P1172	Injection correction resistance value	Injection correction resistance value is too high.
P1176	Maximum speed adjusting resistor	Adjusting resistor value is too low.
P1177	Maximum speed adjusting resistor	Adjusting resistor value is too high.
P1185	Engine stop switch	Engine stop switch is seized closed.
P1200	Injector COM2	COM2 is open or short circuited; or TWV2, TWV4 or TWV6 is open or short circuited.
P1210	Capacitor charging circuit (ECU)	Malfunction in the injector drive power supply circuit (overcharging or insufficient charging).
P1240	Fuel system 1	Large momentary fluctuations in No. 1 cylinder speed.
P1241	Fuel system 5	Large momentary fluctuations in No. 5 cylinder speed.
P1242	Fuel system 3	Large momentary fluctuations in No. 3 cylinder speed.
P1243	Fuel system 6	Large momentary fluctuations in No. 6 cylinder speed.
P1244	Fuel system 2	Large momentary fluctuations in No. 2 cylinder speed.
P1245	Fuel system 4	Large momentary fluctuations in No. 4 cylinder speed.
P1255	Output to SCV	Open circuit (external) in ECU terminal SCV+ or SCV-, GND short, or open circuit in SCV coil.
P1256	Output to SCV	BATT short in ECU terminal SCV+ or SCV-.
P1257	SCV	SCV seizure.
P1262	Exhaust brake MV1	Open circuit or GND short in the output to MV1.
P1263	Exhaust brake MV1	BATT short in the output to MV1.
P1605	ECU	Malfunction in the flash memory.
P1930	Power retarder relay	Open circuit, GND short or BATT short in the output to the retarder relay.